


REMOVABLE SPINDLE OPTION

Patented, other patents pending

- Ability to replace a damaged spindle in the field greatly reduces repair costs by not having to replace the complete axle.
- With only one bolt to remove, the procedure is quick and easy.
- Removal of the spindle requires no special tools.
- A positive spindle location with "D" washer design ensures proper brake flange location for brakes and E-Z Lube[®] hole.



- Clamping bolt and washer are made of stainless steel to resist corrosion resulting in easy removal.
- One spindle will replace either side, no need to order a left hand or right hand side.

FAQs

Can I add this feature to my existing axle?

No, if your axle is not equipped with the removable spindle option, it cannot be added.

Do I have to replace the hubs?

Only if they have been damaged, but you should replace bearing cones, cups and seals.

Can the arm assembly be replaced?

No, it is welded in place.

Can I change to a larger size spindle?

No, each size spindle is made for a specific axle.

Can I change the axle starting angle?

No, the angle is not adjustable.

Will my old hubs fit my replacement spindle?

Yes, the new spindles are sized for the axle capacity.

Do I need special tools to change the spindle?

No, standard hand tools are all that is required.

I can't get the spindle out of the hole.

Follow the Installation/Removal procedure instructions. You may need to drive the wedge in deeper. If rusted, spray with penetrating oil.

The threads are damaged in the arm, can I repair them?

Yes, try cleaning up the threads with a 1/2"-20 thread tapping die.

How long will it take to replace one spindle?

Approximately 15 minutes after hub or hub, drum & brake removal.

Where can replacement spindle kits be purchased?

From Dexter Axle or a Dexter Axle distributor.

Visit **www.dexteraxle.com** to locate your nearest distributor.

