



## 24 Volt Wiring Diagram Evo Controller

24v must be connected after ignition key so switches off when key is turned off

